



NIPPONIA


SUPERQ 110




-  Rojo
-  Azul oscuro
-  Verde
-  Azul claro
-  Amarillo
-  Verde metálico

SPARE PARTS CATALOGUE

v. 24.12

E-1	CYLINDER HEAD				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	12101-C20-0000	CYLINDER ASSY.	1		
2	12009-B01-0000	GASKET, CYLINDER	1		
3	12211-B01-0000	HEAD, CYLINDER	1		
4	809241030080123100	PIN, FIXING 92401-08012	2		
5	91226-B01-0000	SEAL	1		
6	1207A-B01-0000	GASKET COMP., CYLINDER HEAD	1		
7	809241030080143100	PIN, FIXING 92401-08014	2		
8	809210020060321LJA	BOLT, STUD 92120-06032-23	2		
9	90114-B01-0000	BOLT, CYLINDER	2		
10	90604-B01-0000	BUSH	1		
11	90606-B01-0000	BUSH	1		
12	91224-B01-0000	SEAL, RECTANGULAR	1		
13	91225-B01-0000	SEAL, RECTANGULAR	1		

E-2	CYLINDER HEAD COVER			SUPERQ 110	
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	12231-B01-0000	COVER, CYLINDER HEAD	1		
2	12241-C20-0000	COVER, CYLINDER HEAD R.	1		
3	12311-B01-0000	COVER, CYLINDER HEAD L.	1		
4	12301-B01-0000	COVER, VALVE	2		
5	12232-B01-0000	GASKET, CYLINDER HEAD COVER	1		
6	12244-B01-0000	GASKET, CYLINDER HEAD R. COVER	1		
7	12319-B01-0000	GASKET, CYLINDER HEAD L. COVER	1		
8	12405-C20-0000	GASKET, CARBURETOR	1		
9	14801-C20-0000	PIPE, IN	1		
10	91201-C20-0000	O-RING	1		
11	90226-B01-0001	NUT, CAP	4		
12	90435-B01-0000	WASHER	3		
13	90436-B01-0000	WASHER	1		
14	90401-C20-0000	WASHER	1		
15	91222-B01-0000	O-RING	2		
16	809220030060251JJA	BOLT, FLANGE 92140-06025	2		
17	809220030060181JJA	BOLT, FLANGE 92140-06018	2		
18	33300-B01-0100	PLUG, SPARK	1		
19	90115-B01-0000	BOLT, LONG	1		

E-3

CAMSHAFT/VALVE

SUPERQ 110


No	Part No	Part description	Q'ty	Notes	Frame No
1	14705-B01-0000	SEAL, VALVE STEM	2		
2	1411A-B01-0000	CAMSHAFT COMP.	1		
3	14403-B01-0000	ROCKER, VALVE	2		
4	14404-B01-0000	SHAFT, VALVE ROCKER	2		
5	14711-B01-0000	VALVE, IN	1		
6	14712-B01-0000	VALVE, EX.	1		
7	14704-B01-0000	SPRING, VALVE OUTER	2		
8	14703-B01-0000	SPRING, VALVE INNER	2		
9	14702-B01-0000	SEAT, VALVE SPRING	2		
10	14707-B01-0000	RETAINER, VALVE OUTER SPRING	2		
11	14701-B01-0000	CLIP, VALVE	4		
12	14401-B01-0000	SCREW, TAPPET ADJUSTING	2		
13	14402-B01-0000	NUT, TAPPET ADJUSTING	2		


E-4	CAM CHAIN, TENSIONER	SUPERQ 110

No	Part No	Part description	Q'ty	Notes	Frame No
1	14303-B01-0000	SPROCKET, CAM CHAIN DRIVEN	1		
2	14302-C20-0000	CHAIN, CAM	1		
3	1453A-B01-0000	ARM COMP., CAM CHAIN TENSIONER	1		
4	1451A-B01-0000	ROLLER, CAM CHAIN TENSIONER	1		
5	14509-B01-0000	PIVOT, CAM CHAIN TENSIONER ARM	1		
6	14503-B01-0000	SPRING, CAM CHAIN TENSIONER ROD	1		
7	1454A-B01-0000	ROD COMP., CAM CHAIN TENSIONER	1		
8	14545-B01-0000	HEAD, CAM CHAIN TENSIONER ROD	1		
9	14562-B01-0000	ROLLER, GUIDE	1		
10	14551-B01-0000	PIVOT, GUIDE ROLLER	1		
11	1452A-B01-0000	SPROCKET COMP., OIL PUMP	1		
12	14507-B01-0000	SHAFT, OIL PUMP SPROCKET	1		
13	11016-B01-0000	PLUG, BOLT	1		
14	90113-B01-0000	BOLT	3		
15	90403-B01-0000	WASHER	1		
16	90401-C20-0000	WASHER	1		
17	90434-B01-0000	WASHER	1		
18	809220030060181JJA	BOLT, FLANGE 92140-06018	1		

E-5	CRANKCASE	SUPERQ 110

No	Part No	Part description	Q'ty	Notes	Frame No
1	1110B-C14-0000	CRANKCASE, R.	1		
2	11009-B01-0001	GASKET, CRANKCASE	1		
3	1120B-C14-0000	CRANKCASE, L.	1		
4	11006-037-0000	TUBE, VENTILATE	1		
5	11020-B01-0000	CLAMP, OVERFLOW TUBE	1		
6	108180000060161EJA	SCREW M6X16	2		
7	11005-C20-0000	BOLT, STUD A	2		
8	11012-C20-0000	BOLT, STUD B	2		
9	90402-B01-0000	WASHER	1		
10	809241030100143100	PIN, FIXING 92401-10014	2		
11	11015-B01-0000	BOLT, OIL DRAIN	1		
12	1531A-B01-0000	SCREEN, OIL FILTER	1		
13	8092200300606011JA	BOLT, FLANGE 92140-06060B	1		
14	8092200300605011JA	BOLT, FLANGE 92140-06050B	2		
15	8092200300606511JA	BOLT, 92140-06065B	4		
16	15100-B01-0001	PUMP COMP., OIL	1		
17	15111-B01-0000	GASKET, OIL PUMP	1		
18	10081800006022EJA	SCREW M6X22	1		
19	11007-037-0000	CLAMP, VENTILATE TUBE	1		
20	11017-037-0000	CLAMP, TUBE	1		

E-7	STARTER MOTOR				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	31200-037-0000	MOTOR ASSY., STARTER	1		
2	809220030060501JJA	BOLT, FLANGE 92140-06050B	3		
3	24001-C20-0000	SPROCKET, STARTER MOTOR DRIVE	1		
4	1089418601100033JS	CIRCLIP 11	1		
5	801200069431K01900	WIRE, STARTER MOTOR CONNECTING	1		


E-8	L. FR. COVER, GENERATOR				SUPERQ 110	
						
No	Part No	Part description	Q'ty	Notes	Frame No	
1	A6D070-042-01	COVER, L. FR.	1			
2	11411-C20-0000	COVER, L. RR.	1			
3	11309-C20-0000	GASKET, L. FR. COVER	1			
4	3111A-C30-0001	WHEEL COMP., FLYING	1			
5	11002-A25-0000	COVER, PEEP HOLE UPPER	1			
6	11001-A25-0000	COVER, PEEP HOLE	1			
7	809241030080143100	PIN, FIXING 92401-08014	2			
8	11081-A25-0000	O-RING, PEEP HOLE	1			
9	11082-A25-0000	O-RING, PEEP HOLE UPPER	1			
10	31120-042-0100	STATOR COMP.	1			
11	909220030060251JJA	BOLT, FLANGE 92140-06025B	4			
12	909220030060321JJA	BOLT, FLANGE 92140-06032B	2			
13	909220030060501JJA	BOLT, FLANGE 92140-06050B	1			
14	909220030060701JJA	BOLT, FLANGE 92140-06070B	1			
15	90201-B01-0000	NUT, HEXANGULAR	1			
16	809220030060161JJA	BOLT, FLANGE 92140-06016B	1			
17	108230880050161EJA	SCREW M5X16	2			
18	11006-C20-0000	PLATE, PULSER WIRE	1			
19	11004-C20-0000	PLATE, WIRE	1			
20	108230880050051EJA	SCREW M5X5.5	1			


E-9

STARTER CLUTCH

SUPERQ 110

No	Part No	Part description	Q'ty	Notes	Frame No
1	11015-C20-0000	PLATE,COVER	1		
2	24018-C20-0000	CHAIN, ELECTRIC STARTER	1		
3	11017-C20-0000	PLATE, CHAIN GUIDE	1		
4	11018-C20-0000	PLATE, CHAIN TENSION	1		
5	2440A-C20-0001	SPROCKET, ELECTRIC STARTER	1		
6	11016-C20-0000	PLATE, FIXING	1		
7	24300-C20-0001	CLUTCH ASSY., STARTER	1		
8	809220030060121JJA	BOLT, FLANGE 92140-06012	1		
9	10070000060201EJB	SCREW M6X20	3		
10	91201-B01-0000	O-RING	2		
11	31112-B01-0000	O-RING	1		
12	10819000060161EJA	SCREW M6X16	2		
13	91111-B01-0000	SEAL, OIL	1		
14	91101-C20-0000	SEAL, OIL 30X42X4.5	1		

E-10	R. CRANKCASE			SUPERQ 110	
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	1133A-B10-0000	CRANKCASE, R.	1		
2	11019-B01-0001	GASKET, R. CRANKCASE	1		
3	8092410080123100	PIN, FIXING 92401-2-08012	2		
4	11309-B10-0000	BOLT, CLUTCH ADJUSTING	1		
5	1135A-B10-0000	DISK COMP., CAM	1		
6	134521921800075000	O-RING 7.5X1.8	1		
7	1009710202800035JA	WASHER 8	1		
8	16171000080001FJA	NUT M8	1		
9	11301-B10-0000	GAUGE, OIL	1		
10	91205-B01-0000	O-RING	1		
11	91104-B01-0000	SEAL, OIL	1		
12	809220230060401JJA	BOLT, FLANGE 92140-06040B	5		
13	809220230060651JJA	BOLT, FLANGE 92140-06065B	2		
14	809220230060801JJA	BOLT, FLANGE 92140-06080B	1		
15	12005-B01-0000	CLAMP, WIRE	1		

E-11	CLUTCH				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	2151A-B10-0000	LIMITER, CLUTCH	1		
2	21408-B10-0000	SPRING, CAM DISC	1		
3	2142A-B10-0000	DISC COMP., CLUTCH CAM	1		
4	15207-B01-0000	PIPE, OIL SUPPLY	1		
5	15206-B01-0000	SPRING, OIL SUPPLY PIPE	1		
6	102760940000600000	BEARING 100	1		
7	108191000050101EJA	SCREW M5X10	4		
8	21406-B10-0000	COVER, CLUTCH END	1		
9	21407-B10-0000	GASKET, CLUTCH END COVER	1		
10	90202-B01-0000	NUT, ROUND	1		
11	90404-B01-0000	WASHER, DISC	1		
12	90405-B01-0000	WASHER, STOP	1		
13	108180000050101EJA	SCREW M5X10	4		
14	100960020050003SJA	WASHER 5-140HV	4		
15	21102-B10-0000	COVER, CLUTCH OUTER	1		
16	21421-B01-0000	SPRING, CLUTCH MINI	4		
17	21401-B10-0000	SPRING, CLUTCH	4		
18	21120-B10-0000	DISC COMP., CLUTCH DRIVE	1		
19	2102A-B10-0001	PLATE COMP., CLUTCH LOWER	1		
20	2121A-B10-0000	DISC A, CLUTCH FRICTION	2		
21	2122A-B10-0000	DISC B, CLUTCH FRICTIONG	1		
22	21405-B10-0000	SPRING, CLUTCH SEPARATE	4		
23	2101A-B10-0000	PLATE COMP., CLUTCH UPPER	1		
24	21901-B01-0000	CIRCLIP	1		
25	21311-B10-0000	CENTRE, CLUTCH FIXING	1		
26	21312-B10-0000	CENTER, CLUTCH SLIPPERY	1		
27	22101-B10-0000	GEAR, PRIMARY DRIVE	1		
28	21005-C20-0000	BUSH, CLUTCH	1		
29	21911-B01-0000	WASHER, CLUTCH BUSH	1		


E-12


TRANSMISSION

SUPERQ 110

An exploded view diagram of a transmission assembly. The diagram shows the mainshaft (1) and countershaft (2) with their respective gears (3-8). It also includes bearings (9-10), a drive sprocket (11), a friction spring (14), a drum locking plate (15), washers (16-18), a spline washer (17), a circlip (19), a seal (21), a bolt (22), and a bearing (23). The parts are numbered 1 through 23.

No	Part No	Part description	Q'ty	Notes	Frame No
1	22201-B12-0000	MAINSHAFT, TRANSMISSION	1		
2	22202-B12-0000	COUNTERSHAFT, TRANSMISSION	1		
3	22312-B12-0000	GEAR, COUNTERSHAFT 1ST	1		
4	22005-B12-0000	BUSH, COUNTERSHAFT	1		
5	22321-B12-0000	GEAR, MAINSHAFT 2ND	1		
6	22322-B12-0000	GEAR, COUNTERSHAFT 2ND	1		
7	22331-B12-0000	GEAR, MAINSHAFT 3RD	1		
8	22322-B12-0000	GEAR, COUNTERSHAFT 3RD	1		
9	102760940000620100	BEARING 6201	1		
10	102760940000620300	BEARING 6203	2		
11	22401-B10-0000	SPROCKET, DRIVE	1		
12	22402-B01-0000	PLATE, DRIVE SPROCKET FIXING	1		
13	22353-B12-0000	BUSH	1		
14	23352-C20-0000	SPRING, FRICTION	1		
15	23351-C20-0000	PLATE, GEARSHIFT DRUM LOCKING	1		
16	90404-C20-0000	WASHER, PUSHING	1		
17	22002-A25-0000	WASHER, SPLINE	1		
18	90406-B01-0000	WASHER, SPLINE	1		
19	90504-B01-0000	CIRCLIP, MAINSHAFT	2		
20	90506-B01-0000	CIRCLIP, COUNTERSHAFT	1		
21	91101-B01-0000	SEAL, OIL	1		
22	90101-C20-0000	BOLT M6X8	2		
23	102760940000600100	BEARING 6001	1		


E-13		GEARSHIFT			SUPERQ 110	
						
No	Part No	Part description	Q'ty	Notes	Frame No	
1	23101-B01-0000	FORK I, GEARSHIFT	1			
2	23104-B01-0000	PIN, GEARSHIFT FORK GUIDE	2			
3	23103-B01-0000	CLIP, SPRING	2			
4	23201-B12-0000	DRUM, GEARSHIFT	1			
5	23211-B12-0000	PLATE, GEARSHIFT DRUM FIXING	1			
6	90602-C20-0000	PIN, GEARSHIFT FORK 4X12.8	4			
7	2331A-C20-0000	PLATE COMP., FIXING	1			
8	23301-C20-0000	SPRING, RETURN	1			
9	2332A-C20-0000	SPINDLE, GEARSHIFT	2			
10	2351A-B12-0000	ARM, GEARSHIFT	1			
11	23514-B01-0000	SPRING, GEARSHIFT ARM	1			
12	23302-042-0000	SPRING, GERSHIFT ARM RETURN	2			
13	23304-B01-0000	BOLT, FIXING	1			
14	37180-B01-0001	SWITCH, NEUTRAL	1			
15	23213-C14-0000	PIECE, NEUTRAL SWITCH TOUCH	1			
16	11003-016-0000	PLATE, NEUTRAL SWITCH PRESS	1			
17	23111-B12-0000	FORK II, GEARSHIFT	1			
18	23309-C20-0000	BOLT, FLANGE	1			
19	90433-B01-0000	WASHER	1			
20	11018-B01-0000	PLUG, RUBBER	1			
21	91102-B01-0000	SEAL, OIL	1			
22	91202-B01-0000	O-RING	1			
23	157830000060161JJA	BOLT M6X16	1			
24	809220030060121JJA	BOLT, FLANGE 92140-06012	1			
25	90603-C20-0000	PIN, FIXING 3X8.5	2			
26	2361A-B10-0000	LEVER COMP., CLUTCH OPERATION	1			

E-14	KICK STARTER				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	24100-C20-0000	SPINDLE ASSY., STARTER	1		
2	24105-C20-0000	GEAR, STARTER	1		
3	24111-B01-0000	WHEEL, STARTER RACHET	1		
4	24116-B01-0000	PLATE, RACHET WHEEL GUIDE	1		
5	157830000060201JJA	BOLT M6X20	2		
6	24101-C20-0000	SPINLE, STARTER	1		

E-15


CARBURETOR


SUPERQ 110





No	Part No	Part description	Q'ty	Notes	Frame No
1	16100-C20-0000	CARBURETOR ASSY.	1		
2	1660A-C20-0000	NEEDLE, OIL	1		
3	16127-C20-0000	JET, MAIN	1		
4	16126-C20-0000	NOZZLE, MAIN	1		
5	16121-C20-0000	NOZZLE, SECONDARY	1		
6	1630A-C20-0000	VALVE COMP., FLOAT	1		


F-1	HEADLIGHT,METER				SUPERQ 110
 1  7-2  7-1 					
No	Part No	Part description	Q'ty	Notes	Frame No
1	35100-B10-0000-LED	HEADLIGHT ASSY. LED	1		
7-1	A6A008-285-20-1	METER ASSY. DIGITAL	1		
7-2	A6A008-285-20-2	METER ASSY. ANALOGUE	1		
7	36300-B10-0000-1	CABLE, METER DIGITAL	1	AFTER NCD-129	
7	36300-B10-0000-2	CABLE, METER ANALOGUE	1		
8	A6A008-285-10-1	SWITCH ASSY., IGNITION	1		
8	A6A008-285-10-2	SWITCH ASSY., IGNITION	1		


F-2	HANDLEBAR, SWITCH, CABLE				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	61121-B01-0000	GRIP, L.	1		
2	37300-285-0000	SWITCH ASSY., L.	1		
4	108180000050401EJA	SCREW M5X40	2		
5	1009308700500033JS	WASHER 5	1		
6	108180000050101EJA	SCREW M5X10	2		
7	37314-B10-0000	WASHER II, ABNORMAL	1		
8	37313-B10-0000	LEVER, CHOKE	1		
9	100961020050003SJA	WASHER 5	1		
10	6107A-285-0001	CABLE COMP., CHOKE	1		
11	89200-285-0000-R	MIRROR, BACK VIEW	1	ROUND shape	
12	61131-B01-0000	GRIP, R.	1		
13	37400-285-0000	SWITCH ASSY., R.	1		
14	37404-285-0000	LEVER, FR. BRAKE	1		
16	100410000050001DJA	NUT M5	1		
17	108180000050251EJA	SCREW M5X25	2		
19	6103A-285-0000	CABLE COMP., THROTTLE	1		
20	6105A-285-0000	CABEL COMP., FR. BRAKE	1		
22	6111A-285-0000	PIPE COMP., STEERING HANDLE	1		
23	6115A-B10-0000	CONNECTOR, STEERING HANDLE PIPE	1		
24	157870860080551JJA	BOLT M8X55	2		
25	157870860080161JJA	BOLT M8X16	3		

F-3	FR. FORK				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	157870860080301JJA	BOLT M8X30	2		
2	1009308700800033JS	WASHER 8	2		
3	56006-B10-0000	NUT, STEERING STEM FIXING UPPER	1		
4	5642A-A60-0000	SUPPORT COMP., UPPER	1		
5	56400-A60-0000	SEAT ASSY., FR. FORK UPPER SUPPORT	1		
6	56020-B10-0000	BEARING COMP., STEERING STEM UPPER	1		
7	56005-B10-0000	NUT, STEERING STEM FIXING LOWER	1		
8	56004-B10-0000	PLUG, RUBBER	2		
9	56030-B10-0000	BEARING COMP., STEERING STEM LOWER	1		
10	62102-B01-0000	SEAL, DUST	1		
11	90409-B01-0000	WASHER	1		
12	56100-B10-0000	STEM ASSY., STEERING	1		
13	90310-B01-0000	SCREW, SELF-LOCK	2		
14	37100-B01-0000	LOCK, VEHICLE	1		
15	157870860080161JJA	BOLT M8X16	2		
16	1009308700800033JS	WASHER 8	2		
17	100971020080003SJS	WASHER 8-140HV	2		
18	5601A-B10-0000	REFLECTOR	2	WHITE	
19	5604A-B10-0000	NUT, LOCK	2		
20	56001-B10-0000	BOLT	2		
21	5641A-B10-0000	SUPPORT COMP., LOWER	1		


F-4	FR. FENDER				SUPERQ 110	
						
No	Part No	Part description	Q'ty	Notes	Frame No	
1	00119-B10-0000	BOLT, FR. FENDER	2			
2	82131-B10-0000	FENDER, FR.	1	PAINTED PART		
3	82132-B10-0000	BUSH	2			
4	82133-285-0000	STICKER, FR. FENDER	1			
5	82100-B10-0000	FENDER ASSY., FR.	1			


F-5	HEADLIGHT COVER, METER COVER				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	82601-B10-0000	COVER, HEADLIGHT	1		
2	82602-B10-0000	COVER, METER	1		
3	1084508504H01611JA	SCREW, SELF-TAPPING ST4.8x13-C-H	2		
4	1084508500401211JA	SCREW, SELF-TAPPING ST4.2x13-C-H	2		
5	1084508504H03211JA	SCREW, SELF-TAPPING ST4.8x32-C-H	4		

F-6	FR. FORK, FR. FORK ROCK ARM				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	52100-B10-0000	FORK ASSY., FR.	2		
2	157830000080301JJA	BOLT M8X30	2		
3	1009308700800033JS	WASHER 8	2		
4	100971020080003SJA	WASHER 8-140	2		
5	56200-B10-0000	ARM ASSY., FR. FORK L.	1		
6	56300-B10-0000	ARM ASSY., FR. FORK R.	1		





No	Part No	Part description	Q'ty	Notes	Frame No
1	41221-285-0000	RIM, FR. WHEEL	1	ALUMINUM, after NCD-129	
2	41172-285-0000	TUBE, FR. WHEEL	1		
3	10276094063000RS00	BEARING, FR. WHEEL 6300-RS	2		
4	41112-148-0000	AXLE, FR. WHEEL	1		
5	41103-B01-0000	BUSH, FR. WHEEL AXLE	1		
6	4112A-B10-0000	HUB, FR. WHEEL	1		
7	41215-B01-0000	SPOKE, FR. WHEEL OUTER	18		
8	41214-B01-0000	SPOKE, FR. WHEEL INNER	18		
9	4113A-B10-0000	COLLAR, FR. WHEEL BEARING	1		
10	41171-285-0000	TYRE, FR. WHEEL	1		
11	42116-B10-0000	GEAR, FR. BRAKE HELIX	1		
12	4214A-285-0000	COVER COMP., FR. BRAKE	1		
13	4214A-B01-0000	SHOES COMP., FR. BRAKE	2		
14	42202-B01-0000	CAM, FR. BRAKE	1		
15	42114-B01-0000	SPRING, FR. BRAKE SHOES	2		
16	42101-B10-0000	ARM, FR. BRAKE SHORT	1		
17	42107-B10-0000	SPRING, RETURN	1		
18	161770860060001FJA	NUT M6	1		
19	157890860060301JJA	BOLT M6X30	1		
20	41151-B10-0000	NUT	1		
21	1009100002E02231JA	PIN, SPLIT 2.5X22	1		
22	41109-B01-0000	PIN, FR. BRAKE SHORT ARM	1		
23	41216-B01-0000	NUT, FR. WHEEL SPOKE	36		
24	41111-B01-0000	SEAL, OIL	1		


F-8	RR. BRAKE				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	161700000060001FJA	NUT M6	1		
2	41205-B01-0000	AXLE, RR. WHEEL	1		
3	41208-B01-0000	BUSH, RR. WHEEL AXLE	1		
4	4221A-B01-0000	COVER, RR. BRAKE	1		
5	4222A-B01-0000	SHOES, RR. BRAKE	2		
6	42202-B01-0000	CAM, RR. BRAKE	1		
7	42203-B01-0000	INDICATOR, RR. BRAKE	1		
8	42205-B01-0000	SPRING, RR. BRAKE SHOES	2		
9	42201-B01-0000	ARM, RR. BRAKE SHORT	1		
10	42204-B01-0000	GASKET, RR. BRAKE CAM	1		
11	41201-B01-0000	BOLT, RR. BRAKE COVER	1		
12	161700000060001FJA	NUT M6	1		
13	1617000000800001FJA	NUT M8	1		
14	1009710200600033JA	WASHER 6	1		
15	1009710200800033JA	WASHER 8	1		
16	1009308700600033JA	WASHER 6	1		
17	1009308701000033JA	WASHER 10	1		
18	1009100000303031JA	PIN, SPLIT 3X30	1		
19	41202-B01-0000	ADJUSTER, CHAIN R.	1		
20	157820000060351JJA	BOLT M6X35	1		





No	Part No	Part description	Q'ty	Notes	Frame No
1	41241-C10-0000	SPROCKET, RR. WHEEL	1		
2	41213-B01-0000	DAMPER	4		
3	41209-B01-0000	BUSH, RR. WHEEL AXLE	1		
4	41208-B01-0000	COLLAR, RR. WHEEL AXLE	1		
5	41214-B01-0000	HUB, RR. WHEEL	1		
6	41215-B01-0000	SPOKE, RR. WHEEL OUTER	18		
7	41214-B01-0000	SPOKE, RR. WHEEL INNER	18		
8	41231-B01-0000	FLANGE COMP., RR. WHEEL	1		
10	41212-B01-0000	BUSH, BEARING	1		
11	41211-B01-0000	O-RING	1		
12	41221-285-0000	RIM, RR. WHEEL	1	ALUMINUM, after NCD-129	
13	41271-285-0000	TYRE, RR. WHEEL	1		
14	41172-285-0000	TUBE, RR. WHEEL	1		
15	41173-285-0000	BAND, TYRE	1		
16	41206-B01-0000	NUT	1		
17	90204-B01-0000	NUT	4		
18	41233-B01-0000	SEAL, OIL	1		
19	161700000060001FJA	NUT M6	2		
20	41204-B01-0000	NUT	1		
21	100971020060003SJA	WASHER 6	1		
22	100930870060003JS	WASHER 6	1		
23	1009100000303031JA	PIN, SPLIT 3X30	1		
24	41207-B01-0000	ADJUSTER, CHAIN L.	1		
25	102760940000620300	BEARING 6203	1		
26	10276094063010RS00	BEARING 6300-RS	2		

F-10	FUEL TANK				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	8111A-285-0000	TANK COMP., FUEL	1		
2	81211-A55-0000	RING, LOCK B	2		
3	81102-B10-0000	TUBE, FUEL OUTER	1		
4	81101-285-0000	TUBE, FUEL	1		
5	81135-B01-0000	GASKET, FUEL TANK CAP	1		
6	8113A-B01-0000	CAP, FUEL TANK	1		
7	36400-B10-0000	SENSOR, FUEL	1		
8	100971020050003SJA	WASHER 5	4		
9	108180000050101EJA	SCREW M5X10	4		
10	100971020060003SJA	WASHER 6	2		
11	157870860060161JJA	BOLT M6X16	2		

F-11	SEAT, LUGGAGE CARRIER				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	A6D070-285-04	SEAT ASSY.	1		
2	71104-B10-0000	RUBBER B	2		
3	71105-B10-0000	RUBBER A	2		
4	7114A-B10-0000	CONNECTOR, SEAT UNDER	1		
5	A6D059-148F-02	SUPPORT COMP., SEAT	1		
6	157870860080201JJA	BOLT M8X20	2		
7	72500-285-0000	CARRIER ASSY., FR. LUGGAGE	1		
8	72400-285-0001	BASKET, FR. LUGGAGE	1		
9	00001-285-0000	CONNECTOR, FR. LUGGAGE BASKET	1		
10	157830000060251JJA	BOLT M6X25	2		
11	100961020060003SJA	WASHER 6	2		
12	161700000060001FJA	NUT M6	2		
13	71103-B10-0000	RUBBER C	1		
14	72202-B10-0000	HANDREST, R.	1		
15	157870860080161JJA	BOLT M8X16	4		
16	161771000060001FJA	NUT M6	6		
17	7118A-B10-0000	SWITCH, SEAT	1		
18	72201-B10-0000	HANDREST, L.	1		

F-12	SIDE COVER, TOOLS				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	A6G105-285-07	COVER COMP., R. SIDE	1		
2	A6G105-285-06	COVER COMP., L. SIDE	1		
3	82403-285-0000	BOLT, R. SIDE COVER FIXING	1		
4	51004-B01-0000	BOLT, L. SIDE COVER FIXING	1		
5	89100-B01-0000	TOOLS	1		

F-13	AIR CLEANER				SUPERQ 110	
						
No	Part No	Part description	Q'ty	Notes	Frame No	
1	17100-015-0000	CLEANER ASSY., AIR	1			
2	1714A-B10-0000	ELEMENT, AIR CLEANER	1			
3	1712A-B10-0000	HOOP, AIR CLEANER TUBE	1			
4	00117-B10-0000	BOLT	2			


F-14	EXHAUST MUFFLER				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	1801A-B01-0000	GASKET COMP., EXHAUST MUFFLER	1		
2	108230880060081EJA	SCREW M6X8	2		
3	1009308700800033JA	WASHER 6	2		
4	100961020060003SJA	WASHER 6	2		
5	18004-B01-0000	WASHER	2		
6	18001-285-0000	COVER, EXHAUST MUFFLER PROTECTOR	1		
7	18002-285-0000	CONNECTOR, EXHAUST MUFFLER	1		
8	161871000080001FJA	NUT M8	2		
9	161700000080001FJA	NUT M6	2		
10	A6A008-285-12	MUFFLER ASSY., EXHUAUST	1		


F-15

GEASHIFT PEDAL, FOOTREST


SUPERQ 110


No	Part No	Part description	Q'ty	Notes	Frame No
1	2341A-C20-0000	PEDAL COMP., GEARSHIFT	1		
2	24200-B10-0000	ARM COMP., KICK STARTER	1		
3	5413A-285-0000	STAND COMP., SIDE	1		
4	5411A-C20-0000	FOOTREST COMP.	1		
5	54101-B01-0000	RUBBER, FOOTREST	2		
6	54102-B01-0000	BOLT, SIDE STAND CONNCTOR	1		
7	157830000060201JJA	BOLT M6X20	1		
8	157830000060251JJA	BOLT M6X25	1		
9	157830000080161JJA	BOLT M8X16	4		
10	161710000100009HJA	NUT M10X1.25	1		
11	24206-B01-0000	RUBBER, KICK STARTER ARM	1		
12	54103-B01-0000	SPRING, SIDE STAND	1		
13	1009308700800033JS	WASHER 8	4		


F-16	RR. BRAKE ROD, MAIN STAND				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	37800-171-0000	SWITCH ASSY., RR. BRAKE LIGHT	1		
2	00107-B10-0000	SPRING, RR. BRAKE LIGHT SWITCH	1		
3	43101-B10-0000	ROD, RR. BRAKE	1		
4	4311A-B10-0000	ARM COMP., RR. BRAKE	1		
5	00108-B10-0000	SPRING, RR. BRAKE RETURN	1		
6	54209-B10-0000	RUBBER, MAIN STAND	1		
7	51004-B10-0000	PLATE, MAIN STAND SPRING HOOK	1		
8	54200-285-0000	STAND ASSY., MAIN	1		
9	51003-285-0000	AXLE, MAIN STAND	1		
10	1009100000302531JA	PIN 3X25	1		
11	100971020060003SJA	WASHER 6	1		
12	1009100000201631JA	PIN SPLIT 2X16	1		
13	51005-B10-0000	SPRING, MAIN STAND RETURN	1		
14	43103-B01-0000	SPRING	1		
15	43102-B01-0000	PIN	1		
16	43101-B01-0000	NUT	1		





No	Part No	Part description	Q'ty	Notes	Frame No
1	5311A-173-0000	BOX COMP., CHAIN UPPER	1		
2	5312A-173-0000	BOX COMP., CHAIN LOWER	1		
3	25400-171-0000	CHAIN, DRIVE	1		
4	53101-B01-0000	CAP, CHAIN BOX PEEP	1		
5	53100-285-0001	BOX ASSY., CHAIN	1		
6	53007-B01-0000	RUBBER, CHAIN PROTECTOR	1		
7	53002-B01-0000	STOPPER, RR. BRAKE			
8	53001-B01-0000	SPRING, RR. BRAKE STOPPER	1		
9	53003-B01-0000	RUBBER, CHAIN PROTECTOR	2		
10	53004-B01-0000	WASHER, RR.FOOTREST	2		
11	5323A-B01-0000	ROD COMP., RR. FOOTREST	2		
12	5321A-B01-0000	FORK COMP., RR	1		
13	53006-B01-0000	PLUG, RR. FORK RUBBER	2		
14	5324A-B01-0000	RUBBER, RR. FORK	2		
15	100971020060003SJA	WASHER, 6	4		
16	157830000060061JJA	BOLT M6X6	3		
17	51017-B01-0000	AXLE, RR. FORK	1		
18	100410000080001DJA	NUT M8	1		
19	161871000100009HJA	NUT M10X1.25	1		
20	157830000060101JJA	BOLT M6X10	1		
21	100971020060003SJA	WASHER 6	2		
22	100971020100003SJA	WASHER 10	1		
23	100971020100003SJA	WASHER 10	1		
24	1009100000201631JA	PIN, SPLIT 2X16	3		
25	53000-B01-0000	FORK ASSY., RR.	1		


F-18	RR. CUSHION				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	55100-B10-0000	CUSHION ASSY., RR.	2		
2	100971020120003SJA	WASHER 12	2		
3	90205-B01-0000	NUT, CAP	4		
4	100971020100003SJA	WASHER 10	4		


F-19	RR. FENDER				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	82232-B10-0000	FENDER, RR.	1		
2	82202-B10-0000	RUBBER, RR. FENDER DAMPING	1		
3	82208-B10-0000	RUBBER, RR. FENDER	1		
4	82203-B10-0000	CLIP, RUBBER	2		
5	82204-B10-0000	CLIP, DAMPING	2		
6	82201-B10-0000	FIN, RR. FENDER	1		
7	100971020050003SJA	WASHER 5-140HV	2		
8	82206-B10-0000	SCREW	2		
9	00103-B10-0000	BOLT	1		
10	82209-285-0000	STICKER, RR. FENDER R.	1		
11	82205-285-0000	STICKER, RR. FENDER L.	1		
12	00104-B10-0000	WASHER	1		
13	157830000060121JJA	BOLT M6X12	1		
14	100971020080003SJA	WASHER 8	2		


F-20		WINKER			SUPERQ 110	
 1, 5					 7, 9	
No	Part No	Part description	Q'ty	Notes	Frame No	
1	35400-B10-0000	WINKER ASSY., FR. L.	1	WHITE, ROUND		
2	35301-B10-0000	LENS, FR. WINKER	2	WHITE, ROUND		
3	807600870012010A00	BULB (MT12-10A)	4			
4	35303-B10-0000	CASE, WINKER	2			
5	35300-B10-0010	WINKER ASSY., FR. R.	1	WHITE, ROUND		
6	35601-148-0301	LENS, RR. L. WINKER	1	WHITE, ROUND		
7	35600-B10-0301	WINKER ASSY., RR. R.	1	WHITE, ROUND		
8	35501-B10-0301	LENS, RR. R. WINKER	1	WHITE, ROUND		
9	35500-B10-0301	WINKER ASSY., RR. L.	1	WHITE, ROUND		

F-21	TAILLIGHT			SUPERQ 110	
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	35200-285-0001	TAILLIGHT ASSY.	1		
2	35201-285-0000	LENS, TAILLIGHT	1		
3	1F766195P215W12215	BULB 12V21W/5W	1		
4	00101-B10-0000	RUBBER, TAILLIGHT	2		
5	90501-148-0000	BOLT	2		

F-22	ELECTRIC PARTS				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	3311A-A01-0000	PLUG, SPARK	1		
2	33100-B10-0000	COIL, IGNITION	1		
3	32100-C30-0000	RECTIFIER	1		
4	157830000060121JJA	SCREW M6X12	2		
5	37300-A25-0300	RELAY, WINKER	1		
6	32200-A55-0000	BATTERY	1		
7	33200-C20-0000	CDI UNIT	1		
8	34300-148-0301	WIRE, TAILLIGHT	1		
9	34100-285-0000	WIRE, MAIN	1		
10	34103-B10-0000	FUSE	1		
11	51231-A25-0000	BAND	2		
12	34500-285-0000	HORN	1		
13	00116-B10-0000	COVER, AIR CLEANER	1		
14	37700-C30-0000	RELAY, STARTING	1		

F-23	FRONT PANEL				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	82811-148-0000	COVER, FR. UPPER	1		
2	82822-B10-0000	COVER, FR. LOWER	1		
3	A5B001-148F-01	EMBLEM, FR. COVER	1		
4	82813-B10-0000	CIRCLIP	2		
5	00115-148-0000	SCREW, CROSS	1		
6	157870860080501JJA	BOLT M8X50	1		
7	82821-A60-0000	COLLAR	1		

F-24	FRAME				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	51100-B10-0000	FRAME COMP.	1		
2	A6G105-285-04	STICKER, FRAME L.	1		
3	A6G105-285-05	STICKER, FRAME R.	1		
4	5126A-B10-0000	SUPPORT, RR. FENDER	1		
5	157870860080161JJA	BOLT M8X16	2		
6	5101A-B10-0000	NUT, FLANGE	2		
7	8079509700B901C00	EMBLEM, JL90-1	1		
8	108270860020043600	RIVET 2X6	2		
9	89510-198-0000	LOCK, HELMET	1		
10	89310-285-0001	LOCK, HELMET L.	1		
11	157870860060101JJA	BOLT M6X10	2		
12	5121A-B10-0000	SCALEBOARD COMP., INNER	1		
13	161770860060001FJA	NUT M6	2		
14	5127A-285-0000	SUPPORT, FR. COVER	1		
15	51273-B10-0000	RUBBER	1		
16	157830000060121JJA	BOLT M6X12	4		
17	5123A-285-0000	SUPPORT, CDI UNIT	1		
18	157870860060121JJA	BOLT M6X12	5		
19	161770860080001FJA	NUT M8	1		
20	00010-285-0000	PLATE, BATTERY PRESS	1		
21	51240-285-0001	SUPPORT, BATTERY	1		
22	157830000060251JJA	BOLT M6X25	2		
23	56021-B10-0000	CIRCLE, STEERING STEM BEARING SEAT	2		
24	00005-285-0000	BOLT, ENGINE UPPER FIXING	1		
25	90103-B01-0000	BOLT, ENGINE LOWER FIXING	1		
26	100971020080003SJA	WASHER 8-140HV	1		
27	1009308700800033JS	WASHER 8-140HV	1		
28	161700000080001FJA	NUT M8	2		

F-25	WINDSHIELD			SUPERQ 110	
					
No	Part No	Part description	Q'ty	Notes	Frame No
1	82501-B10-0000	WINDSHIELD	1		
2	00114-B10-0000	HOOK, WINDSHIELD	1		
3	157830000060201JJA	BOLT M6X20	2		
4	00104-B10-0000	WASHER	3		
5	1578100000060701JJA	BOLT M6X70	2		
6	109230880080001FJA	NUT M8	2		
7	100971020080003SJA	WASHER 8-140-HV	2		
8	00111-B10-0000	PLATE, WINDSHIELD PRESS	2		
9	00113-B10-0000	PIPE, R.	1		
10	82612-148-0100	MARK, GEAR	1		
11	81106-A25-0000	MARK, WARNING	1		
12	82504-B10-0000	COVER, SPARK PLUG ADJUSTING	1		
13	82503-B10-0000	COVER, CARBURETOR ADJUSTING	1		
14	0003A-285-0000	PIPE, L.	1		

F-26	CARRIERS				SUPERQ 110
					
No	Part No	Part description	Q'ty	Notes	Frame No
1		FRONT BASKET	1		
2		MIDDLE CARRIER	1		