




MAGNETO XP




-  Azul
-  Rojo
-  Negro
-  Gris

SPARE PARTS CATALOGUE

version: 25.09

NE125				
No.	Part.No	Description	Quantity	Remarks
E-1 CYLINDER HEAD COVER				
				
1	120230121-0002	cylinder head	1	
2	380840889-0001	gasket	1	
3	380450391-0001	washer6.2X12X1.2	1	
4	380140129-0001	bolt	1	
5	380140016-0001	bolt	4	
6	380600057-0001	locating pin	1	


E-2 CYLINDER HEAD



1	120080689-0002	cylinder head	1	
2	120120052	intake valve tube	2	
3	120150200-0001	washer,cylinder head	1	
4	120300028-0001	left side cover, cylinder head	1	
5	380840890-0001	gasket	1	
6	180430083	intake pipe body	1	
7	380960216	clamp	2	
8	180420630-0001	inlet tube	1	
9	180440040	flange plate	1	
10	270960058-0001	spark plug	1	
11	380140548-0001	bolt	1	
12	380180162-0001	double-headed bolt	2	
13	380340035-0002	nut	4	

14	380450925-0001	washer	4	
15	380600029-0001	locating pin	2	
16	380840330	gasket	1	
17	380140021-0002	bolt	2	
18	380140016-0005	bolt	3	
19	380140131-0002	bolt	2	
20	380840008	gasket	2	
21	380140143-0001	bolt	2	


E-3 CAMSHAFT/VALVE



1	140400002-0001	Assembly Overrunning Clutch	2	
2	140020111-0001	Gamshaft Comp	1	
3	140450061-0001	Rocker Arm Assembly, Valve	2	
4	140510053-0001	Rocker shaft	1	
5	140300082	intake valve	1	
6	140310084	exhaust valve	1	
7	140350023-0001	Outer valve spring	2	
8	140380002	valve spring,retainer	2	
9	140370002-0001	Outer valve spring,retainer	2	
10	140390002	Valve Locker	4	
11	380140334-0001	bolt M5X14	2	
12	140480026	adjustment bolt, valve	2	

13	140490003	tightening nut, valve	2	
14	140510052-0001	arm rocker shaft	1	
15	500550074-0001	valve comp.	1	
16	500730002-0001	valve spring, retainer	2	


E-4 CHAIN/TENSIONER



1	140580039-0001	timing driving sprocket	1	
2	140610013-0001	timing chain	1	
3	141160002-0001	Tension arm	1	
4	141210011-0001	Tension wheel	1	
5	380822800-0001	sleeve	1	
6	380822801-0001	sleeve	1	
7	381150030-0001	spring	1	
8	141080002-0001	tensioner rod, chain	1	
9	141100001	tensioner head, chain	1	
10	141240012-0001	guiding wheel, chain	1	
11	141270003-0003	shaft, guiding wheel pin	1	
12	141240014-0001	guiding wheel, chain	1	


13	110260004-0004	plug screw	1	
14	380710025-0001	bolt/screw and washer comp.	1	
15	380450927-0001	washer	1	
16	380450928-0001	washer	1	
17	380450391-0001	washer	1	
18	380450056-0001	washer	1	
19	380450054-0001	washer	1	
20	380140103-0001	bolt	2	
21	380140129-0001	bolt	1	

E-5 CYLINDER



1	120020241-0001	cylinder body	1	
2	120050097-0001	gasket,cylinder body	1	
3	380600029-0001	locating pin	2	


E-6 RIGHT CRANKCASE COVER



1	110600563-0012	crankcase cover, R	1	
2	110620065-0001	gasket, rankcase cover, R	1	
3	110700080-0001	oil ruler	1	
4	190810066-0002	Clutch controlling rod	1	
5	381160177-0002	spring	1	
6	191230034-0003	locating plate	1	
7	380940650-0002	clip	1	
8	380450391-0001	washer	1	
9	380600002-0001	locating pin	2	
10	380650013-0001	oil seal	1	
11	380840083-0001	gasket	1	
12	380840006-0001	gasket	1	

13	380140030-0003	bolt	11	
----	----------------	------	----	--


E-7 CLUTCH



1	190330057	cluch cover assy.	1	
2	380822802	sleeve	1	
3	190400039	clutch center sleeve assy.	1	
4	190430041	Rub slice	4	
5	190460037	Steel slice	3	
6	190470032	Press plate	1	
7	190480023	Rose plank	1	
8	190550053	main spring, clutch	4	
9	190730028	Push lever	1	
10	380140103	bolt M6X25	4	
11	380370084	nut M14	1	
12	380450929	washer $\Phi 17 \times 29.5 \times 1.5$	1	
13	380450930	washer $\Phi 14 \times 26 \times 3$	1	


14	380630240	bearing 6200	1	
15	500280215-0001	clutch assy.	1	

E-8 STARTING CLUTCH




1	193240037-0001	disk gear	1	
2	193090001	starting clutch	1	
3	193190034-0001	starting motor, duplicate gear	1	
4	193230024-0001	shaft reduction	1	
5	380190195	screw	3	
6	380822805	sleeve	1	

E-9 LEFT CRANKCASE COVER




1	110400275-0012	left front cover	1	
2	110520679-0002	left rear cover	1	
3	110420037-0001	gasket,crankcase cover,L	1	
4	110440013-0001	Cap view hole	1	
5	110430036-0001	decorative cover, L	1	
6	380600002-0001	locating pin	2	
7	380840026-0001	gasket $\phi 13.8 \times 2.5$	1	
8	380840245-0001	gasket $\phi 31.7 \times 2.4$	1	
9	380140143-0001	bolt	2	
10	380140030-0003	bolt	6	
11	380140032-0001	bolt	2	

E-10 GENERATOR



1	270020238	rotor assy,magneto	1	
2	270100138	stator,magneto	1	
3	380450259-0001	washer	2	
4	380370005-0001	hexagon flange nut	2	
5	380140002-0006	hexagon head flange bolt	1	
6	380140021-0002	hexagon head flange bolt	3	
7	270010241-0001	magneto	1	


E-11 OIL PUMP



1	380840892-0001	gasket	1	
2	150010077-0001	oil pump	1	
3	150140010-0001	gasket, oil pump body	1	
4	150070041	driving gear	1	
5	150050041	Inner rotor ,oil pump	1	
6	150060039	Outer rotor, oil pump	1	
7	150290002-0001	Oil mesh screen	1	
8	150490015-0001	Oil filter seat	1	
9	150540011-0001	gasket, Oil filter cover	1	
10	150360029-0001	Oil filter cover	1	
11	380370084	bolt M14	1	
12	380450930	washer $\Phi 14.X26X3$	1	
13	380450933	washer $\Phi 9X14X1$	1	

14	380600002-0001	locating pin	1	
15	380310161	screw	1	
16	380570001	split washer	1	
17	380140209-0003	bolt	3	
18	380140030-0003	bolt M6X35	3	
19	380600180	locating pin Φ 3X16	1	


E-12 CRANKCASE



1	110080210	crankcase body, R	1	
2	110030328	crankcase body, L	1	
3	120340003-0001	backflow baffle plate	1	
4	270650087-0001	switch, gear display		
5	270740001	Press plate	1	
6	110240056-0001	double-headed bolt A	4	
7	380450018-0003	washer	1	
8	191380005-0001	stop plate,main shaft bearing	1	
9	380600001-0001	locating pin	2	
10	380650184-0001	oil seal	1	
11	110260003-0006	plug screw	1	
12	380140013-0001	bolt	1	
13	380140129-0001	bolt	2	


14	380140019-0003	bolt	9	
15	380140032-0001	bolt	3	
16	500270288-0001	crankcase body comp.	1	
17	380740022-0001	breather pipe	1	
18	380950016-0001	clip	1	

E-13 CRANKSHAFT/PISTON



1	130140175-0002	Crankshaft and connecting rod comp	1	
2	130070196-0001	piston ring	1	
3	130030223-0001	piston	1	
4	130060066-0001	piston pin	1	
5	380560109-0001	Retaining ring	2	
6	380822803-0001	sleeve	1	
7	190030048-0001	primary driving gear	1	
8	380620002	Semicircular Key	2	
9	380630409	bearing	1	
10	380630408	bearing	1	
11	130230045	timing driving sprocket	1	


E-14 TRANSMISSION



1	191260064	main shaft	1	
2	191400100	counter shaft	1	
3	380822806	sleeve	1	
4	191420046	gear c-1	1	
5	191280035	gear m-2	1	
6	191440038	gear c-2	1	
7	191290035	gear m-3	1	
8	191460039	gear c-3	1	
9	191300029	gear m-4	1	
10	191480037	gear c-4	1	
11	191600013-0001	driving sproket, counter shaft	1	
12	191610002-0001	Fixing Plate	1	

13	380822807	bushing	1	
14	380540141	circlip	1	
15	380540142	circlip	1	
16	380500037	circlip	2	
17	380500038	circlip	1	
18	380550171	circlip	2	
19	380550172	circlip	1	
20	380630033-0001	bearing	1	
21	380630013-0001	bearing	1	
22	380630002-0001	bearing	1	
23	380650061-0001	oil seal	1	
24	380070141-0001	bolt	2	
25	191250092	transmission mainshaft	1	
26	191390163	transmission countershaft	1	
27	500290228-0001	mainshaft and counter shaft comp.	1	


E-15 TRANSMISSION



1	192120065	fork1	1	
2	192120064	fork2	1	
3	192130029	Shifting fork shaft	1	
4	192080066	Gearshift Drum	1	
5	192100024-0001	Shift plate comp.	1	
6	192190022-0001	stop plate comp.	1	
7	381160178-0001	spring	1	
8	192320089-0001	shaft, gear shaft	1	
9	381160180	spring	1	
10	192310007-0001	locating bolt	1	
11	270720008	Contact Gear indication	1	
12	380190008-0005	bolt	1	


13	192240007-0001	screw, stop screw	1	
14	380450227-0001	washer	1	
15	380540143	circlip	1	
16	380550173	circlip	1	
17	380600181	locating pin	2	
18	380190005-0002	screw	1	
19	192060083-0001	Gearshift Drum comp.	1	

E-16 KICK STARTER SPINDLE




1	193320025	Starting gear	1	
2	193330015	Starting ratchet	1	
3	193310043	Starting shaft	1	
4	193470016	Return spring seat	1	
5	380822804	sleeve	1	
6	193340036	Return Spring,Kick Starting Shaft	1	
7	193350017	spring	1	
8	380450931	wassher	1	
9	380450932	washer	1	
10	380550009	circlip	1	
11	380550065	circlip	1	
12	193300069-0001	Start shaft assy	1	

E-17 STARTING MOTOR




1	270350056-0001	starting motor	1	
2	380140103-0001	bolt	2	
3	270390001-0010	wire, starting motor	1	




F-1 Speedometer and ignition lock

No.	Part No.	Part Description	Q'ty	Unit
1	351000-8390	Meter assy, digital	1	PCS
2	GB/T5789	Bolt M8×12	2	PCS
3	360000-8398	Lock assy (ignition lock & keys)	1	PCS
4	GB/T70.1	Bolt M6×16	2	PCS
5	350200-8026	Meter holder	1	PCS
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-2 Steering stem,Upper Connecting plate

No.		Part Description	Q'ty	
1	906203-	Bolt	1	PCS
2	503001-	upper and lower	2	SET
3	GB/T70.1	Bolt M8×45	4	PCS
4	503100-8070	Upper Connecting plate	1	PCS
5	503703-0002	Upper ball cover	1	PCS
6	503600-	Upper ball	1	PCS
7	503702-8003	Lower bowl	1	PCS
8	503600-	Lower ball	1	PCS
9	503312-0001	Dust seal	1	PCS
10	503003-8001	Adjusting nut, steering stem	1	PCS
11	503300-8084	Steering stem	1	PCS
12	GB/T9074.17	Bolt M10×1.25×35	2	PCS
13	501007-8014	Holder, Front fork plate	1	PCS
14	906210-	Screw M6×20	2	PCS
15	501018-8042	decorative cover, front fork	1	PCS
16	503701-8002	Upper bowl	1	PCS
17				
18				
19				
20				




F-3 Headlight,Front turning signal


No.		Part Description	Q'ty	
1	GB/T 5783	Bolt M8*25	2	PCS
2	GB/T93	Spring washer Φ8	2	PCS
3	GB/T96.1	Flat washer Φ8	2	PCS
4	904107-	Rubber ring	2	PCS
5	331000-8152	Headlight assy	1	PCS
6	333500-8105	Front right turning signal	1	PCS
7	906210-	Screw M5×16	2	PCS
8	904283	Upper rubber, headlight holder	2	PCS
9	331300-8091	Right hoder, headlight	1	PCS
10	904284	Lower rubber, headlight holder	2	PCS
11	331200-8091	Left holder, headlight holder	1	PCS
12	333400-8105	Front left turning signal	1	PCS
13				
14				
15				
16				
17				
18				
19				
20				




F-4 Handlebar assembly,Cable				
No.		Part Description	Q'ty	
1	600200-	Right handle grip, XP	1	PCS
2	372200-8020	Right handle lever	1	PCS
3	904101-0002	cable ties	4	PCS
4	904299-8003	Handle lever cover	2	PCS
5	904101	Rubber ties	2	PCS
6	600001-8107	Handle bar	1	PCS
7	371200-8135	Right handle switch	1	PCS
8	372100-8024	Left handlde lever	1	PCS
9	371100-8139	Left handle switch	1	PCS
10	350500-8160	Odometer cable	1	PCS
11	607000-8114	Throttle cable	1	PCS
12	606000-8261	Clutch cable	1	PCS
13	605000-8093	Front brake cable		
14		Left handle grip		
15				
16				
17				
18				
19				
20				




F-5 Rear view mirror				
No.		Part Description	Q'ty	
1	901100-8223	Left rear view mirror	1	PCS
2	901200-8223	Right rear view mirror	1	PCS
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-6 Front reduction, Front fender				
No.		Part Description	Q'ty	
1	GB/T5789	Bolt M10×1.25×20	2	PCS
2	906217-	Washer M10×1.25×20	2	PCS
3	804002-8012	Front smaller fender	1	PCS
4	GB/T9074.6	Bolt M6×16	2	PCS
5	804100-8645	Front fender	1	PCS
6	GB/T9074.1	Bolt M6×16	4	PCS
7	501100-8172	Front left shock absorber	1	PCS
8	502000-8173	Righe shock absorber	1	PCS
9	GB/T6177	Nut M6	2	PCS
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-7 Front wheel				
No.		Part Description	Q'ty	
1	423000-8057	Front brake	1	PCS
2	902101-8038	Front wheel axle	1	PCS
3	404001-8150	Front outer tire	1	PCS
	404100-8021	Front inner tire	1	PCS
4	402000-8207	Front wheel assy.	1	PCS
5	400102-8001	Inner tire valve	1	PCS
6	902202-8044	Right sleeve, front wheel axle	1	PCS
7	GB/T6187	Nut, front wheel axle M12	1	PCS
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				




F-8 Frame and bracket				
No.		Part Description	Q'ty	
1	511000-8264	Frame assy	1	PCS
2	904239	Side cover rubber	4	PCS
3	GB/T6177	Bult M8	4	PCS
4	GB/T5789	Bolt M8×70	2	PCS
5	GB/T5789	Bolt M8×90	1	PCS
6	GB/T5789	Bolt M8×95	1	PCS
7	GB/T5789	Bolt M10×110	2	PCS
8	510020-8054	Engine holder	1	PCS
9	GB/T6177	Nut M10	2	PCS
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				



F-9 Main bracket, side bracket				
No.		Part Description	Q'ty	
1	GB/T6177	Nut M10×1.5 green	1	PCS
2	530100-8061	Side stander	1	PCS
3	906205-8006	Bolt 10×35×1.5,green	1	PCS
4	530005-8008	Spring hook, main stand	1	PCS
5	GB/T91	Pin 3×30	1	PCS
6	906217-	Flat washer 17×26×2	1	PCS
7	530006-8029	Spring, main stand	1	PCS
8	530001-8001	Spring, side stand	1	PCS
9	902103-8023	Axle, main stand	1	PCS
10	530600-8105	Main stand	1	PCS
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-10 Engine, carburetor				
No.		Part Description	Q'ty	
1	110000-8851	Engine	1	PCS
2	100004-8015	Carburetor joint	1	PCS
3	100005-	sealing gasket	1	PCS
4	100013	Heat insulated pad	1	PCS
5	161000-8174	Carburetor	1	PCS
6	220000-8024	Start lever	1	PCS
7	211000-8029	Geer shifting lever	1	PCS
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-11 Cables and electrical components				
No.		Part Description	Q'ty	
1	372301-	Cable, front brake switch	1	PCS
2	904101-	cable ties	3	PCS
3	304000-8225	Ignition coil	1	PCS
4	306500-0001	Flasher	1	PCS
5	307200-8002	Rear brake switch	1	PCS
6	302000-8029	Voltage rectifier	1	PCS
7	GB/T5789	Bolt M6×12	2	PCS
8	GB/T9074.1	Bolt M5×20	1	PCS
9	GB/T5789	Bolt M6×12	2	PCS
10	305000-8031	Igniter	1	PCS
11	301000-8021	Start Relay	1	PCS
12	GB/T5789	Bolt M6×12	1	PCS
13	307000-8247	Main cable	1	PCS
14	312000-0005	Horn	1	PCS
15	318300-8020	USB	1	PCS
16				
17				
18				
19				
20				




F-12 Guard bar, pedal				
No.		Part Description	Q'ty	
1	GB/T5789	Bolt M8×16 army green	2	PCS
2	713200-8111	Left pedal. rear rack	1	PCS
3	713300-8111	Right pedal, rear rack	1	PCS
4	GB/T70.2	Bolt M8×30	2	PCS
5	GB/T6177	Nut M8	2	PCS
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-13 Air filter, battery				
No.		Part Description	Q'ty	
1	170000-8099	Air filter	1	PCS
2	303000-8081	Battery	1	PCS
3	906204-0001	U-shape nut M6	3	PCS
4	GB/T5789	Bolt M6×16	3	PCS
5	303200-8010	Battery holder	1	PCS
6	161000-8174	Carburator	1	PCS
7	GB/T6170	Nut M6	2	PCS
8	100005-	sealing gasket	1	PCS
9	100013	Heat insulated pad	1	PCS
10	904302-	Oil pipe	1	PCS
11	160100-8001	Fuel filter	1	PCS
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-14 Brake pedal, foot pedal				
No.		Part Description	Q'ty	
1	430400-8102	Rear Brake pedal	1	PCS
2	904225-	Front right footrest	1	PCS
3	GB/T5789	Nut M10×1.25×25	5	PCS
4	906122-0002	Washer φ6	1	PCS
5	904286-	Raer right footrest	1	PCS
6	GB/T5789	Bolt M10×1.25×55	1	PCS
7	430500-8075	lever	1	PCS
8	904224-	Front left foot rest	1	PCS
9	430002-8017	Spring, rear brake switch	1	PCS
10	GB/T91	Pin 3×30	1	PCS
11	906217-	Flate washer 17×26×2	1	PCS
12	906117-0001	2*16	1	PCS
13	904285-	Rear left footrest	1	PCS
14	430001-8041	Spring, brake pedal	1	PCS
15				
16				
17				
18				
19				
20				




F-15 Muffler				
No.		Part Description	Q'ty	
1	GB/T923	Bolt M8×22	2	PCS
2	180001-8004	sealing gasket	1	PCS
3	181000-8145	Muffler	1	PCS
4	180200-	Muffler decoration	1	PCS
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-16 Fork				
No.		Part Description	Q'ty	
1	902104-8052	Axle, rear fork	1	PCS
2	GB/T6187	Nut M14	1	PCS
3	906205-0002	Bolt	1	PCS
4	523100-8134	Rear fork	1	PCS
5	906121-0001	Flat washer ϕ 8	1	PCS
6	906125-0001	Spring washer ϕ 8	1	PCS
7	GB/T6177	Nut M8	1	PCS
8	906117-0001	2*16	1	PCS
9	904306-	Chain sliding block	1	PCS
10	523004-8028	Torsion bar	1	PCS
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-17 chain box				
No.		Part Description	Q'ty	
1	522000-8041	Upper, chain box	1	PCS
2	522000-8041	Lower, chain box	1	PCS
3	907392-8018	Chain adjust label	1	PCS
4	907393-8026	Tire pressure label	1	PCS
5	904202-0001	Access cover,chain	1	PCS
6		Nut		
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




F-18 Rear shock absorber				
No.		Part Description	Q'ty	
1	GB/T97.1	Nut $\Phi 12$	4	PCS
2	540300-8189	Rear shock absorber	2	PCS
3	906217-8001	Outer washer, rear shock absorber	4	PCS
4	906110-0001	Nut, rear shock absorber	4	PCS
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				



F-19 Chain wheel,chain				
No.		Part Description	Q'ty	
1	405001-8003	Lock plate,chain wheel	2	PCS
2	GB/T5782	Bolt M8×35	4	PCS
3	231000-8027	Chain	1	PCS
4	405100-8070	chain wheel	1	PCS
5	409001-8043	Cushion seat	1	PCS
6	906249-8001	Nut M8	4	PCS
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				



F-20 Rear wheel				
No.		Part Description	Q'ty	
1	408001-8140	Rear outer wheel	1	PCS
	408100-8030	Rear inner wheel	1	PCS
2	406000-8200	Rear wheel assy.	1	PCS
3	405005-	Cushion rubber	1	PCS
4	GB/T6187	Nut M14	1	PCS
5	GB/T6170	Nut M8	2	PCS
6	906103-0004	Bolt M8*60	2	PCS
7	906205-0003	Bolt	1	PCS
8	424000-8109	Rear brake	1	PCS
9	904293-0001	Gasket, torson bar	1	PCS
10	902204-8054	Right sleeve, rear wheel	1	PCS
11	902203-8055	Left sleeve, rear wheel	1	PCS
12	906121-0001	Flat washer Φ8	1	PCS
13	906125-0001	Spring washer Φ8	1	PCS
14	GB/T6177	Nut M8	1	PCS
15	906117-0001	2*16	1	PCS
16	523200-8032	Chian adjuster	1	PCS
17	902102-8039	Rear wheel axle	1	PCS
18	400102-8001	Inner tire alve	1	PCS
19				




F-21 Rear fender				
No.		Part Description	Q'ty	
1	805200-8028	Front section, rear fender	1	PCS
2	805100-8071	Rear fender	1	PCS
3	906241-	Clip	2	PCS
4	725002-8003	Box lid	1	PCS
5	306400-0005	Rear reflector	1	PCS
6	GB/T6177	Nut M6	4	PCS
7	GB/T5789	Bolt M6×12	4	PCS
8	903019-	Advertise board	1	PCS
9	171800-8001	Dust cover, air filter	1	PCS
10	GB/T96.1	Φ8×24×2	2	PCS
11	GB/T5789	Nut M8×25	2	PCS
12	GB/T5789	Nut M6×12	1	PCS
13	511051-8014	Cable clip	1	PCS
14	GB/T6177	Nut M6	1	PCS
15	805004-8025	Rear license holder	1	PCS
16	805006-	Rear license holder decoration	1	PCS
17				
18				
19				
20				




F-22 Fuel tank				
No.		Part Description	Q'ty	
1	801000-0795	fuel tank,black	1	PCS
	801000-0796	fuel tank,blue	1	PCS
	801000-0797	fuel tank,red	1	PCS
2	904236-0003	Rear rubber pad, fuel tank	1	PCS
3	904288-0002	Rear sleeve rubber, fuel tank	2	PCS
4	904289-8001	Bush, fuel tank	2	PCS
5	904287-8001	Front rubber ring, fuel tank	2	PCS
6	360000-8398	Lock assy, fuel tank	1	PCS
7	906112-0002	Bolt GB/T818M4*6	2	PCS
8	904239	Upper rubber, side cover	2	PCS
9	308500-8036	Fuel sensor	1	PCS
10	GB/T6177	Nut M6	4	PCS
11				
12				
13				
14				
15				
16				
17				
18				



F-23 Side cover				
No.		Part Description	Q'ty	
1	806201-8041	Right side cover	1	PCS
2	904239-0003	Lower rubber ring, side cover	2	PCS
3	806101-8041	Left side cover	1	PCS
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				



F-24 Seat				
No.		Part Description	Q'ty	
1	906105-0025	Bolt, seat GB/T 5789 M8*12	2	PCS
2	701000-8463	Seat assy.	1	PCS
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				



F-25 Rear carrier,Taillight,Rear turning signal				
No.		Part Description	Q'ty	
1	906217-8001	Outer washer, rear shoke absorber 10×30×3	4	PCS
2	906110-0001	Nut,rear shoke absorber	4	PCS
3	906105-0032	Bolt,rear rack GB/T5789-M8×25	2	PCS
4	906124-0006	Nut M10 army green	2	PCS
5	906210-	Screw M5×16	2	PCS
6	333600-8113	Rear right turning signal	1	PCS
7	713100-8295	Rear rack	1	PCS
8	906124-0006	Nut M10 army green	2	PCS
9	906122-0002	Flat washer	2	PCS
10	904297-	Rubber ring, Tail light	2	PCS
11	333600-8113	Rear left turning signal	1	PCS
12	332000-8095	Tail light assy.	1	PCS
13				
14				
15				
16				
17				
18				
19				
20				